



G350/1 and G350/2 Ranges

Spares Information

G350/1

Spares No.	Description
539110010	Door Seal (Horizontal)
539110020	Door Seal (Vertical)
539210510	Flue Grid
539210520	Pan Support
539210550	Hob Casting Spacer
539210590	Front Hob Rail
539210600	Rear Cheek - LH
539210610	Rear Cheek - RH
539210620	Side Cheek - LH
539210630	Side Cheek - RH
539210680	Door Seal Bracket (Horiz.)
539210690	Door Seal Bracket (Vert.)
539210700	Oven Hanger
539210710	Oven Bottom Tray
539210720	Drip Tray
539210730	Oven Hanger Bracket
539210741	Door Catch
539210760	Oven Grid Shelf
539210790	Door Hinge (LH - Bottom)
539210800	Door Hinge (RH - Bottom)
539220010	Outer Side - LH
539220020	Outer Side - RH

Fitments

Spares No.	Description
539220030	Adjustable Leg
539220050	Front Frame Assembly
539220060	Front Frame Seal Channel
539220070	Front Frame Seal c/w Clips
539220080	Hob Support - LH
539220090	Hob Support - RH
539220100	Flue Front
539220110	Flue Back Trim
539220120	Door Assembly - LH
539220130	Outer Door Panel - LH
539220140	Inner Door Panel - LH
539220150	Door Handle
539220160	Door Hinge (LH - Top)
539220170	Door Assembly - RH
539220180	Outer Door Panel - RH
539220190	Inner Door Panel - RH
539220200	Door Hinge (RH - Top)
539220290	Control Panel
539220300	Drip Tray - LH
539220310	Drip Tray - RH
539220440	Badge
539110031	Door Catch Keeper Bracket

Falcon Catering Equipment

HEAD OFFICE and WORKS

PO Box 37, Foundry Loan, Larbert,
Stirlingshire. Scotland. FK5 4PL

SERVICE LINE CONTACT -

PHONE - 01438 751111
FAX - 01438 369900

RZZ 242 Ref.1

G350/1

Controls

Spares No.	Description
539110160	Earth Pin
539110170	Electrode
539110190	Electrode Lead c/w Tube
539110200	Ceramic Bush
539110210	Spark Igniter
539110240	Flame Failure Device
539110250	Oven Thermocouple
539110752	Oven Bypass Screw (Prop.)
539110753	Oven Bypass Screw (Nat.)
539110754	Oven Thermostat (Nat.)
539110755	Oven Thermostat (Prop.)
539220040	Oven Injector (Natural)
539220045	Oven Injector (Propane)
539220210	Knob for Oven Thermostat
539220220	Float Rail Assembly
539220230	Burner Support - Rear
539220240	Burner Support - Front
539220250	Burner Pipe (LH - Front)
539220260	Burner Pipe (RH - Front)

Spares No.	Description
539220270	Burner Pipe (LH - Rear)
539220280	Burner Pipe (RH - Rear)
539220320	Burner (Natural Gas)
539220325	Burner (Propane Gas)
539220330	Hob Thermocouple (Long)
539220340	Hob Thermocouple (Short)
539220350	Knob for Control Tap
539220360	Control Tap (Natural Gas)
539220365	Control Tap (Propane Gas)
539220370	Hob Bypass Screw (Nat.)
539220375	Hob Bypass Screw (Prop.)
539220380	Oven Burner (Nat. & Prop.)
539220390	Injector Holder (Natural)
539220395	Injector Holder (Propane)
539220400	Injector Jet (Natural)
539220405	Injector Jet (Propane)
539220410	Burner Head Assembly
539220420	Burner Cap Assembly
539220430	Oven Burner Pipe

G350/2

Spares No.	Description
539110010	Door Seal (Horizontal)
539110020	Door Seal (Vertical)
539110031	Door Catch Keeper Bracket
539110480	Cup Lifter
539210510	Flue Grid
539210590	Front Hob Rail
539210600	Rear Cheek - LH
539210610	Rear Cheek - RH
539210620	Side Cheek - LH
539210630	Side Cheek - RH
539210680	Door Seal Bracket (Horiz.)
539210690	Door Seal Bracket (Vert.)
539210700	Oven Hanger
539210710	Oven Bottom Tray
539210720	Drip Tray
539210730	Oven Hanger Bracket
539210741	Door Catch
539210760	Oven Grid Shelf
539210790	Door Hinge (LH - Bottom)
539210800	Door Hinge (RH - Bottom)
539210870	Hob Casting
539210890	Hob Cup

Fitments

Spares No.	Description
539220010	Outer Side Panel - RH
539220020	Outer Side Panel - LH
539220050	Front Frame Assembly
539220060	Sealing Channel
539220070	Front Frame Seal c/w Clips
539220080	Hob Support - LH
539220090	Hob Support - RH
539220100	Flue Front
539220110	Flue Back Trim
539220120	Door Assembly - LH
539220130	Outer Door Panel - LH
539220140	Inner Door Panel - LH
539220150	Door Handle
539220160	Door Hinge (Top - LH)
539220170	Door Assembly - RH
539220180	Outer Door Panel - RH
539220190	Inner Door Panel - RH
539220200	Door Hinge (Top - RH)
539220440	Badge
539220460	Control Panel
539220030	Adjustable Leg

G350/2

Spares No.	Description
539110160	Earth Pin
539110170	Electrode
539110190	Electrode Lead c/w Tube
539110200	Ceramic Bush
539110210	Spark Igniter
539110240	Flame Failure Device
539110250	Oven Thermocouple
539110260	Pilot Burner (Natural Gas)
539110261	Pilot Burner (Propane Gas)
539110270	Pilot Jet (Natural Gas)
539110280	Pilot Jet (Propane Gas)
539110300	Solid Top Burner
539110310	Solid Top Thermocouple
539110752	Oven Bypass Screw (Prop.)
539110753	Oven Bypass Screw (Nat.)

Controls

Spares No.	Description
539110754	Oven Thermostat (Nat.)
539110755	Oven Thermostat (Prop.)
539210840	Governor
539210910	Burner Pipe - Top
539210920	Pilot Pipe
539220040	Oven Injector (Natural)
539220045	Oven Injector (Propane)
539220210	Knob for Oven Thermostat
539220380	Oven Burner (Nat. & Prop.)
539220450	Float Rail Assembly
539220470	Knob for Solid Top Control
539220480	Control for Solid Top
539220490	Oven Burner Pipe
539110301	Solid Top Injector (Natural)
539110302	Solid Top Injector (Propane)