

PARTI DI RICAMBIO
PIECES DETACHEES
SPARE PARTS
ERSATZTEILE
LISTA DE RECAMBIOS

LF 315
LF 320
LF 320 A
LF 323
LF 323 A

9/94

LF 350
LF 350 A

7/2000




09 - 2000 | S. AG.

LF320


Hood

Table 1




LF320

Tank





05 - 2002 S. AG.

LF320
Wash



LF320

Wash arm




LF320



Rinse assembly




LF320

Control box LF320 - LF323 - LF350



LF320
Wash pump



05 - 2001 | S.A.G.

LF320
Rinse aid injector


02 - 2004 | S. AG.


LF320

Drain pump



07 - 2001 S.A.G.

LF320
Detergent dispenser



09 - 2000 S. AG.