

Machine	Explode	Code	Description
Buffalo Chamber Vacuum Pack Machine	1	<b>*</b>	M6 Stainless Steel Screw
Buffalo Chamber Vacuum Pack Machine	2	<b>~</b>	Handle
Buffalo Chamber Vacuum Pack Machine	3	<b>~</b>	M6 Stainless Steel Nut
Buffalo Chamber Vacuum Pack Machine	4	AE931	Heat-sealing Foam
Buffalo Chamber Vacuum Pack Machine	5	<b>*</b>	Seal Bar (assembly)
Buffalo Chamber Vacuum Pack Machine	6	<b>*</b>	Clamp Fixing-spring
Buffalo Chamber Vacuum Pack Machine	7	<b>*</b>	Clamp
Buffalo Chamber Vacuum Pack Machine	8	<b>~</b>	Connector for Inlet Valve
Buffalo Chamber Vacuum Pack Machine	9	<b>*</b>	L Shaped Connector
Buffalo Chamber Vacuum Pack Machine	10	<b>*</b>	Piston (assembly)
Buffalo Chamber Vacuum Pack Machine	12-17	AE935	Air inlet/ outlet valve & Copper connector
Buffalo Chamber Vacuum Pack Machine	18,18P	<b>*</b>	Motor
Buffalo Chamber Vacuum Pack Machine	11	<b>*</b>	T Shaped Connector
Buffalo Chamber Vacuum Pack Machine	19	<b>*</b>	Rubber Pad
Buffalo Chamber Vacuum Pack Machine	20	AF369	Main PCB
Buffalo Chamber Vacuum Pack Machine	21	<b>*</b>	Insulating Strip for PCB
Buffalo Chamber Vacuum Pack Machine	22	<b>*</b>	Bottom Board
Buffalo Chamber Vacuum Pack Machine	23	<b>*</b>	Signal wire
Buffalo Chamber Vacuum Pack Machine	24	<b>*</b>	Rubber Foot
Buffalo Chamber Vacuum Pack Machine	25	AE932	Control Board (assembly)
Buffalo Chamber Vacuum Pack Machine	26	<b>*</b>	Mounting Plate for Control Panel
Buffalo Chamber Vacuum Pack Machine	27	<b>*</b>	Pressure Gauge
Buffalo Chamber Vacuum Pack Machine	28	<b>*</b>	Power Switch
Buffalo Chamber Vacuum Pack Machine	29	<b>*</b>	Machine Body
Buffalo Chamber Vacuum Pack Machine	30	<b>*</b>	Power cord
Buffalo Chamber Vacuum Pack Machine	31	<b>*</b>	Plug
Buffalo Chamber Vacuum Pack Machine	32	<b>*</b>	Connecting Board
Buffalo Chamber Vacuum Pack Machine	33	<b>*</b>	Back Panel
Buffalo Chamber Vacuum Pack Machine	34	<b>~</b>	Connector for Power Cord
Buffalo Chamber Vacuum Pack Machine	35	AE934	Valve
Buffalo Chamber Vacuum Pack Machine	36	<b>~</b>	Micro Switch Mount
Buffalo Chamber Vacuum Pack Machine	37	AF411	Micro Switch
Buffalo Chamber Vacuum Pack Machine	38	<b>~</b>	Hinge
Buffalo Chamber Vacuum Pack Machine	39	<b>*</b>	M5 Stainless Steel Nut
Buffalo Chamber Vacuum Pack Machine	40	<b>*</b>	Pneumatic Arm
Buffalo Chamber Vacuum Pack Machine	41	2	Right Spring Fixing Plate
Buffalo Chamber Vacuum Pack Machine	42	<b>~</b>	M5 x 16 Stainless Steel Screw
Buffalo Chamber Vacuum Pack Machine	43	2	Strut
Buffalo Chamber Vacuum Pack Machine	44	<b>*</b>	Insulating Strip for PCB
Buffalo Chamber Vacuum Pack Machine	45	AE933	PCB
Buffalo Chamber Vacuum Pack Machine	47	2	Vacuum Chamber
Buffalo Chamber Vacuum Pack Machine	48	AE930	Sealing Ring
Buffalo Chamber Vacuum Pack Machine	49	2	Lid
Buffalo Chamber Vacuum Pack Machine	50	<b>**</b>	Pressing Plate