



**CATALOGO RICAMBI  
SPARE PARTS  
PIECES DETACHEES  
ERSATZTEILE  
LISTA DE RECAMBIOS**





**Lavastoviglie  
Dishwashers  
Lavevaisselle  
Geschirrspüler  
Lavavajillas**



**C 53 E - C 53 E D  
C 60 E - C 60 E D  
SP 45 E - SP 45 E D  
SP 50 E - SP 50 E D**





Ed.	09/2004
Rev.	
Data	









**C 53 E**  
**SP 45 E**





**C 60 E**  
**SP 50 E**















 **Fig. 12**









Ed.	09/2004
Rev.	
Data	





# C 53 E SP 45 E







# C 60 E SP 50 E











**36943**

