


Service Replacement Parts

From TRS Serial Numbers 29241 Onwards



Service Replacement Parts

From TRS Serial Numbers 29241 Onwards

Item	Part No	Description	Qty	Item	Part No	Description	Qty
1	TRS 4255	Feedstick	1	48	TRS 3600	Screw	4
2	TRS 6025	Feed Arm	1	51	TRS 4261	Body	1
3	TRS 4271	Bush	2	52	TRS 3047	Bearing	1
4	TRS 3713	Hinge Pin	2	53	TRS 3081	Seal	1
5	TRS 3215	Cap	1	54	TRS 4263	Retaining Cover	1
6	TRS 3618	Grub Screw	1	55	TRS 3680	Key	1
7	TRS 3398	Magnet	1	56	TRS 4262	Drive Shaft	1
8	TRS 4257	Locking Lever	1	57	TRS 3726	Pin	1
9	TRS 4253	Cover	1	58	TRS 4277	Ejector Plate	1
10	TRS 4258	Hinge Pin	1	59	TRS 3715	Hinge Pin	1
13	TRS 6099	Arm	1	60	TRS 286	Grommet	1
14	TRS 4281	Bush	1	70	TRS 5882	Motor, 240V 50Hz 1ph	1
15	TRS 3102	Seal	1	71	TRS 3332	Auxiliary Contacts 240V	1
16	TRS 3057	Circlip	1	72	TRS 6380	Switch Mounting Block	1
17	TRS 4282	Plunger	1	73	TRS 3672	Screw 4 x 16mm	2
18	TRS 4275	Spring	1		TRS 1430	M4 Washer	2
19	TRS 4272	Switch Mounting Block	1		TRS 3651	M4 Nut	2
20	TRS 3567	Screw 3 x 20mm	1	74	TRS 6376	Switch Mounting Plate	1
	TRS 3747	M3 Washer	1	75	TRS 3499	Screw 5 x 12mm	2
	TRS 3650	M3 Nut	1		TRS 3767	Washer	2
21	TRS 3569	Screw 4 x 8mm	1	76	TRS 1127	Capacitor Holder	1
	TRS 1430	M4 Washer	1	77	TRS 3569	Screw 4 x 8mm	1
22	TRS 4259	Cam	1	78	TRS 3404	Supply Cable	1
23	TRS 3534	Screw, M4 x 20mm Lg & M4 Nut	1	79	TRS 3675	Capacitor Maxistart 80MF 240V	1
29	TRS 3504	Screw, M6 x 10mm Lg	4	80	TRS 2401	Fuse Holder Plate	1
30	TRS 4270	Motor Mounting Plate	1	81	TRS 6373	Fuse Holder	1
31	TRS 3499	Screw, M5 x 12mm Lg	4	82	TRS 3585	Screw 3 x 8mm	2
	TRS 5867	M5 Washer	4	83	TRS 3569	Screw 4 x 6mm	2
32	TRS 3588	Screw, M6 x 50mm Lg	1	84	TRS 4970	Klixon Relay	1
	TRS 3755	M6 Washer	1	85	TRS 3571	Screw 4 x 12mm	1
33	TRS 4268	Motor Pulley	1	86	TRS 2959	Contact Block	1
35	TRS 3632	Screw, M5 x 10mm Lg	2	87	TRS 3589	Screw 4 x 6mm	1
36	TRS 4278	Casing	1	88	TRS 5191	Relay	1
37	TRS 4279	Leg	2	89	TRS 3565	Screw 3 x 8mm	2
38	TRS 4280	Foot	4		TRS 3747	M3 Washer	2
39	TRS 3594	Screw, M5 x 16mm Lg	4	90	TRS 3467	Cable Clamp	1
	TRS 3753	M5 Washer	4	91	TRS 3529	Screw 3 x 16mm	2
	TRS 1182	M5 Nut	4		TRS 3747	M3 Washer	2
40	TRS 3582	Screw, M5 x 80mm Lg	2		TRS 3650	M3 Nut	2
42	TRS 3677	M14 Nut	1	92	TRS 3397	Switch	1
43	TRS 3762	M14 Washer	1	93	TRS 3326	Stop Push Button	1
44	TRS 4266	Driven Pulley	1	94	TRS 3325	Start Push Button	1
45	TRS 3020	Belt	1	95	TRS 5190	Microswitch	1
46	TRS 3041	Bearing	1				
47	TRS 4264	Spacer	1				